## **BURL & VENEER FLATTENING FORMULA**

- 4 OZ. GLYCERINE
- 4 OZ. WHITE GLUE
- 4 OZ. ALCOHOL
- 12 OZ. WATER

APPLY TO BOTH SIDES OF BURLVENEER, WETTING THOROUGHLY.

WIPE OFF EXCESS LIQUID AFTER ABOUT 1/2 MINUTES.

PLACE ALTERNATE LAYER OF BURL/VENEER, BROWN GROCERY SACK PAPER, (WITH ANY PRINTING AWAY FROM BURL/VENEER) AND APPROX. 1/8" NEWSPAPER UNDER MODERATE PRESSURE FOR APPROX. 10 MINUTES. REPLACE BROWN PAPER & BACK UNDER MODERATE PRESSURE FOR ABOUT ONE HOUR.

REPLACE BROWN PAPER & PLACE UNDER FAIRLY HEAVY PRESSURE FOR 24 HOURS. (A CHANGE OF THE BROWN PAPER ONCE DURING THIS PERIOD WILL ENHANCE DRYING FOR STORAGE AFTER DRYING KEEP FLAT WWEIGHTS.